

Documentation

EQTrace OPT+



Contents

Functionality	4
Installation	4
LED - conditions	5
Connection table	5
Wiring of the relay	6
Login to the portal	6
Machine parameters	7
Device parameters	8
Automatic operation detection switched off	8
Automatic operation detection switched on: Diesel machine	9
Automatic operation detection switched on: battery machine	9
Deep discharge message	10
Usage data collection	10
Position determination - map view	11
Theft monitoring ATS	12
Notification	13
Function monitoring	13
Additional functions	14
Service settings	14
Service log book	15
Winter service	15

Export function	16
Key functions	17
Connection of the key module	17
Usage of the key function	18
Evaluation of the key data	19
Technical data	20
Scope of delivery	20

Functionality

The EQTrace OPT+ is a GPS monitoring device that provides the following functions:

- Usage data acquisition on analog input (4 digital inputs can be booked)
- Determination of the current position
- Anti-theft function
- World wide usable
- Daily status report
- Battery status including deep discharge monitoring
- 1 output (optional)

Due to the simple installation and the minimal power consumption in sleep mode, it can be used in many areas. Some usage examples: motor vehicles, construction machinery, truck, boats, mobile homes, antique car, ...

The data is transmitted via mobile Internet (LTE) to the Obserwando server www.obserwando.de. All data can be called up in the Obserwando portal with the respective vehicle name. All data are also available on the Android smartphone or the iPhone via the Obserwando Mobile app.

The SIM card is part of the annual flat rate. It is factory fitted and activated upon delivery.

Installation

The EQTrace OPT+ should be installed as horizontally as possible and with the flange side down at the greatest possible distance from shielding metal parts in order to ensure maximum GPS reception. If the device is installed under metal, an external GPS antenna (optional) should be connected.

The housing can be painted in the vehicle color. If metallic paint is used, an external GPS antenna should be connected.

The EQTrace OPT+ can be installed in vehicles and machines with an operating voltage of up to 60VDC. Installation in cars, trucks, construction machinery, aerial work platforms or forklifts is therefore possible without any problems. For higher operating voltages, appropriate voltage converters (e.g. TR 40-150 or TR-230VAC) are required.

In order to ensure anti-theft protection even when the vehicle is switched off, the device must be connected to a permanent voltage of 10...60VDC.

LED - conditions

After the operating voltage has been applied, the following states are displayed via the built-in LEDs:

red LED

1. LED flashes briefly every 2 seconds: The device is switched on.
2. LED flashes briefly every 5 seconds: The device is in power-saving mode.
3. LED flashes twice briefly every 5 seconds: The device is in power-saving mode while it is awake.

green LED

1. LED is off: The device is not logged into the LTE network, no GPS reception yet.
2. LED flashes briefly every second: The device is logged into the LTE network, but no GPS reception yet.
3. LED flashes long every second: The device has an internet connection and is connected to the server, but no GPS reception yet.
4. LED flashes long and twice briefly every second: The device has an Internet connection and is connected to the server, GPS reception is available.


The LEDs are visible on the underside of the device. When installed, they are covered (protection against manipulation and theft). The assignment can be seen on the nameplate.

Connection table:

white	VPP (PLUS,MAX)
brown, green	GND (minus)
yellow	Input 1 (ignition)
grey	Input 2
pink	Input 3
red	Input 4
blue	Output (max 500 mA, switches to minus)

Wiring of the relay

With the EQTrace OPT+, an output for blocking a function on the vehicle used can be booked (Is not included in the basic package). In vehicles, for example, the starter can be blocked, in work platforms, lifting, etc.




Attention:

A freewheeling diode must be used when switching inductive loads (e.g. power relays).

Login to the portal


You log in to the portal with your user name and password. If you are new to Obserwando, please enter the supplied user ID as the user name and password.



The login form features a yellow background with a black and yellow chevron border at the top. The word 'OBSERWANDO' is written in yellow on a black background. Below this, the word 'Login' is written in blue. There are two input fields: 'User name' and 'Password'. A yellow 'Login' button is positioned below the input fields. At the bottom of the form, there is a message: 'To access this restricted area you need access authorisation.'

Machine parameters

You can start setting up the machine in the following mask.



The screenshot shows a web form titled "Machine parameters" with a yellow background. At the top, there are two dropdown menus: "Machine group" with the value "all" and "Machine" with the value "LL703". A "Show" button is to the right of the "Machine" dropdown. Below these are several input fields: "Machine name" (text input with "LL703"), "Car registration" (text input with "LL 703"), "Machine group" (dropdown menu with "None"), "Upload new picture" (a "Browse..." button and a "No file selected." message), "Delete image" (a checkbox labeled "Don't use any image for this machine"), "Label input 1" (text input with "Input 1"), "Label input 2" (text input with "Input 2"), "Description" (a large empty text area), and "IPAF category" (dropdown menu with "None requi"). A "Save" button is located at the bottom left of the form.

The following fields are available:

Machine name: When the device is delivered, the serial number is here. You are free to choose the device name. It will then appear in all machine selections.

Car registration: For a vehicle, you can enter the license plate number here.

Machine group: Once you have set up machine groups (e.g. rental, service vehicles, etc.), you can assign the device to the desired machine group.

Upload new picture: You can upload a picture of the machine in JPG format. The image size must not exceed 1MB.

Label input 1/2: Enter the channel texts for the inputs here.


Description: Memo field for any text entry.

IPAF category: Currently irrelevant.

Once you have made the desired entries, the entries are saved with "Save".

Device parameters

After selecting this menu item, the following mask appears:



With the EQTrace OPT+ devices, various operating states can be automatically detected.

However, since this method does not work reliably with every machine, the necessary settings can also be made manually.


Important note: The channels record "to the minute".

Automatic operation detection switched off

To do this, select "Automatic operation detection: none"

If the machine has an operating hours counter, the current value n can be accepted for channel 1 (ignition) or channel 2 (engine running).

With a battery machine, channel 1 is reserved for "battery charging". You must "switch on" the loading channel by defining channel 1 as loading channel. Channel 4 could record the times of use, e.g. over the pump running time. To activate the settings, the "Save" button must be clicked.




Automatic operation detection switched on: Diesel engine

If you want to use the automatic operation detection for a diesel machine, select "Automatic operation detection: Combustion engine "motor runs"".

The operating voltage of the battery must also be selected. "12V" and "24V" are available for selection.

The voltage threshold is predefined, but can also be set individually for the machine. The operating hours are automatically recorded on channel 2.

To activate the settings, the "Save" button must be clicked.



Automatic operation detection

Machine group: all | Machine: Test 1 | Show

Automatic operation detection

keine

Combustion engine "motor runs"

Battery-driven machine "motor runs"

Voltage threshold motor runs:


Save

Automatic operation detection switched on: battery machine

If you want to use the automatic operation detection for a battery machine, select "Automatic operation detection: Battery-driven machine "motor runs"".

The selection of the charging voltage is also required. The voltage threshold for the connected charger is preset, but can be adjusted individually for each machine.

To activate the settings, the "Save" button must be clicked.



Automatic operation detection

Machine group: all | Machine: Test 1 | Show

Automatic operation detection

keine

Combustion engine "motor runs"

Battery-driven machine "motor runs"

Absenkungsschwelle:

Channel:

Save

Deep discharge notification

If the battery voltage of the machine falls below the preset value, the Obserwando portal can send a corresponding message via e-mail. For this, the "Activate" check box must be clicked under the "Device parameters" menu item in the "Deep discharge message" section.

To monitor a deep discharge the minimum permissible battery voltage must be specified. You can also select a user who should be informed of the deep discharge.

Caution: Only users for whom a valid e-mail address was stored in the user administration appear in the selection menu.

The duration of the deep discharge can be seen from the battery diagram in the operating data.

To activate the settings, the "Save" button must be clicked.

Deep discharge notification

activate

Voltage

User

Send data

Usage data collection

Weekly data


Machine group: all | Machine: 868324021128199 | from: 2020-08-01 | to: 2023-09-01

Settings Show Print

Channel	Operating hours
0	


Machine service
No service has been set up for the machine, or all appointments have been completed.

battery voltage diagram





868324021128199

cw	day of the week	Start	stop	total	actual -	
2022 - 47	21/11/2022 - Monday	15:52	15:52	00:00	00:01	▼
2022 - 47	23/11/2022 - Wednesday	17:15	17:24	00:09	00:04	▼
2022 - 48	29/11/2022 - Tuesday	11:53	12:55	01:01	00:10	▼
2022 - 49	09/12/2022 - Friday	14:12	14:12	00:00	00:01	▼
Total				01:10	00:16	




Usage data (e.g. motor) can be recorded on one channel in the basic device. If this is not sufficient, additional channels can be booked as an option. The input voltage range of the inputs is between min. 10V and max. 60V. The operating data is automatically transmitted from the device to the server. You can view the recorded operating data in Obserwando under "Machine data" → "Operating data". All days of the week on which the machine worked will appear in this view. Days of the week without work are hidden in the default settings, but can be shown under "Settings". The "Start" column shows the time when the machine started for the first time. In the "Stop" column you will find the time when the machine last switched off. The difference between the two times forms the "Total" value. If you are interested in the effective running time, e.g. motor, you can define the corresponding input channel in the settings for the effective value calculation. You will find the effective total of the running times in the "Effective" column.

Principle of data acquisition

"Start time", "Stop time" and "Minutes per hour" are recorded as usage times. This type of data acquisition has proven particularly useful for aerial platforms and other construction machinery. You will see the timeline for the effective channel for a day by clicking on the yellow arrow  in the last column. If you are interested in the data of all input channels, switch to the day view by clicking on the calendar symbol  in the last column.

Times marked in red in the "Total" and "Effective" columns indicate usage times over 8 hours or at weekends.

Position determination - Map view



If the vehicle is idle, the last reported position is always displayed. If the vehicle is parked for more than 10 minutes, the EQTrace OPT+ switches to sleep mode. This is interrupted every 24 hours in order to submit a control report to Obserwando. If a new position is available, the position is also updated. When driving, the current position is checked every 60 seconds. If the mobile network is not available, the coordinates are saved in the device. As soon as the mobile network is available again, the stored data is transmitted to the server.

During the first start-up, the current position is transmitted to Obserwando as soon as it has been determined after the supply voltage has been connected.

However, the vehicle must be outside!

If no new position can be determined, the last saved position will be displayed.

Theft monitoring ATS

Theft surveillance in Obserwando is divided into rest area and work area surveillance.

Alarm Settings

Machine group: all Machine: 868324021128199

General

activate monitoring

Automatically update centre of rest and work area at the end of a route

Rest area monitoring


Mon	to	06:00	o'clock	and again from	18:00	o'clock
Tue	to	06:00	o'clock	and again from	18:00	o'clock
Wed	to	06:00	o'clock	and again from	07:00	o'clock
Thu	to	06:00	o'clock	and again from	18:00	o'clock
Fri	to	06:00	o'clock	and again from	18:00	o'clock
Sat	up	00:00	o'clock	to	24:00	o'clock
Sun	up	00:00	o'clock	to	24:00	o'clock

Monitor work area

radius km

While saving, redefine centre of work area after last transmitted location.


Aktueller Standort (09/12/2022 14:12)



Google Maps interface showing a red location pin in Heiligenfelde, near Kolonie Wachendorf. The map includes a person icon, zoom controls, and Google logo.

The idle time can be set individually for each day of the week. During the quiet time, an alarm message is given as soon as the quiet area radius of 200 m is left. The adjustable working range (radius in km) is monitored during working hours. The center of the rest or work area is either the last transmitted (i.e. the current position of the machine when defining the area) or the last used position (set as the current position in a previous session).

Notification



Notification

Machine group: all Machine: 868324021128199 User: Demo Ac

activate:-----

Activate SMS notification

Email

Period:-----

from to

Days:-----

Monday	<input type="checkbox"/>	but not	<input checked="" type="checkbox"/>	up	22:00	to	06:00
Tuesday	<input checked="" type="checkbox"/>	but not	<input checked="" type="checkbox"/>	up	06:00	to	22:00
Wednesday	<input checked="" type="checkbox"/>	but not	<input type="checkbox"/>	up	00:00	to	24:00
Thursday	<input checked="" type="checkbox"/>	but not	<input type="checkbox"/>	up	00:00	to	24:00
Friday	<input checked="" type="checkbox"/>	but not	<input type="checkbox"/>	up	00:00	to	24:00
Saturday	<input type="checkbox"/>	but not	<input checked="" type="checkbox"/>	up	00:00	to	24:00
Sunday	<input type="checkbox"/>	but not	<input checked="" type="checkbox"/>	up	00:00	to	24:00

The alarm messages will be sent from the server to all users activated for the device via SMS and/or email. It is important that a valid mobile telephone number and/or e-mail address is entered for the respective user in the master data. After sending an alarm message, monitoring for the device will be disabled to prevent repeated SMS/emails.

Warning: To get a new alarm message, monitoring must be reactivated (see alarm settings).

Function monitoring

After installation of an EQTrace OPT+ device on a machine, the GPS tracker reports to the Obserwando server every minute with the current data. If the machine is not used (weekend, hibernation), the EQTrace OPT+ reports to the Obserwando server every 24 hours.

These status reports from all GPS trackers can be viewed in the machine overview.

Additional functions that can be booked as an option

Service settings

Service intervals and annual inspections such as TÜV or UVV can be specified in the service settings. When a reporting date is reached, it will be displayed in the operating data. It is also possible to notify a user via e-mail. This must be selected in the "User" field.

The fields mean in detail:

- Name:** Event name.
- Hour limit:** Message when the stored number of operating hours has been reached.
- Km limit:** Message when the stored number of kilometers (determined via GPS tracking) has been reached.
- Current mileage:** Entry of the mileage read from the speedometer. This is accepted by selecting "update".
- Date:** A message is issued when the entered date is reached.

Under "Notification" a user with a valid e-mail address must be selected who will be informed by e-mail when an event is reached. To activate the settings, the "Save" button must be clicked.

Service settings

Machine group: Machine:

TÜV

type	Thresholds	delete
Date	<input type="text" value="28/02/2025"/> <input type="button" value="X"/> <input type="button" value="+"/> <input type="button" value="X"/>	<input type="button" value="X"/>
Kilometerstand	<input type="text" value="20000 km"/> <input type="button" value="X"/> <input type="button" value="+"/> <input type="button" value="X"/>	<input type="button" value="X"/>
Operating hours Motor läuft	<input type="text" value="5000 h"/> <input type="button" value="X"/> <input type="button" value="+"/> <input type="button" value="X"/>	<input type="button" value="X"/>
Operating hours Channel 2	<input type="text" value="2500 h"/> <input type="button" value="X"/> <input type="button" value="+"/> <input type="button" value="X"/>	<input type="button" value="X"/>

Service log book (only available as an option, not included automatically)

Entries about the machine, e.g. comments on service intervals or damage, but also photos or circuit diagrams can be stored in the machine file.

To create a new entry, the corresponding button must be selected.



The screenshot shows a yellow header with the title "Service log book". Below the title are three search fields: "Machine group" with a dropdown menu showing "all", "Machine" with a dropdown menu showing "Test 1", and "Search criterion" with an empty text input field. To the right of the "Search criterion" field is a "Show" button. Below these fields is a "New log" button.

You can use the "Search criterion" field to search for a specific entry in the machine file of the selected machine. For example, if you enter the term "damage" in the "Search criteria" field, all existing entries containing the term "damage" will be displayed.

If you click on the "New entry" button, the following page opens:



The screenshot shows a yellow header with the title "Service log book" and a subtitle "Service log for Test 1". Below the subtitle is a "Summary" label followed by a text input field. Below that is a "Text" label followed by a large text area. At the bottom left, there is an "Attachment (max. 5 MB)" label. To its right is a file selection interface with a "Durchsuchen..." button and the text "Keine Datei ausgewählt." followed by a close button "[x]". Below the attachment section is a "File to be attached" label. At the bottom right of the form is a "Save" button.

You can add a summary, a text and one or more attachments in one entry in the machine file. Finally, click on the "Save" button.

Winter service (only available as an option, not included automatically)

You can use the "Winter Service" function to document spreading and clearing distances.

The usage times with the route driven can be recorded at 15s intervals.

Via Obserwando.de you can see exactly which route was taken at what time and which function was used (clearing or spreading). Hardware channels 1 and 2 are required to use this function.


Fahrstrecken-Report

Maschine	Schneepflug	
Datum	von 14.10.20 00:00	bis 14.10.20 23:59
Erstellt am	03.11.2020	
Fahrer		
Kunde		
Straße		
PLZ/Ort		
Auftrags-Nr.		
<input type="button" value="Weiter"/>		

Schneepflug


Zeit	Strecken	Räumen	Ort	Straße
15:02			Start 14.10.20	
15:02 an	aus		28816 Stuhr Rodendamm 19	
15:19 an	aus		28816 Stuhr Betsbruchdamm 30	
15:19 an	aus		28816 Stuhr Betsbruchdamm 27	
15:20 an	aus		28816 Stuhr Betsbruchdamm 20	
15:21 an	aus		28816 Stuhr Betsbruchdamm 20	
15:21 an	aus		28816 Stuhr Betsbruchdamm 16	
15:21 an	aus		28816 Stuhr Betsbruchdamm 14	
15:21 an	aus		28816 Stuhr Bruchstraße 12	
15:22 an	aus		28816 Stuhr Bruchstraße 16	
15:22 an	aus		28816 Stuhr Bruchstraße 16	
15:22 an	aus		28816 Stuhr Bruchstraße 12	
15:22 an	aus		28816 Stuhr Bruchstraße 2	
15:23 an	aus		28816 Stuhr Vorsteher-Kirchhoff-Straße 9	
15:23 an	aus		28816 Stuhr Kirchstraße 1	
15:23 an	aus		28816 Stuhr Kirchstraße 1	
15:24 an	aus		28816 Stuhr Bremer Straße 54	
15:24 an	aus		28816 Stuhr Bremer Straße 63	
15:24 an	aus		28816 Stuhr Ernst-Abbe-Straße 1	
15:24 an	aus		28816 Stuhr Rodendamm 2	
15:25 an	aus		28816 Stuhr Rodendamm 9	
15:25 an	aus		28816 Stuhr Rodendamm 11	
15:26 an	aus		28816 Stuhr Rodendamm 11	
15:26 an	aus		28816 Stuhr Betsbruchdamm 30	
15:29 an	aus		28816 Stuhr Rodendamm 19	
15:52 an	aus		28816 Stuhr Rodendamm 19	
15:52			Stopp 14.10.20	
16:01			Start 14.10.20	
16:01 aus	an		28816 Stuhr Betsbruchdamm 20	
16:02 aus	an		28816 Stuhr Betsbruchdamm 30	
16:02 aus	an		28816 Stuhr Rodendamm 19	
16:04 aus	an		28816 Stuhr Rodendamm 19	
16:50 aus	an		28816 Stuhr Rodendamm 19	
16:50			Stopp 14.10.20	

Effektive Fahrzeit 01:38
 Gesamtzeit 01:47
 Gefahrene Strecke 2.07



Export function (only available as an option, not included automatically)

The export function enables you to export the recorded data in order to be able to evaluate them externally.



With the export function, start times, daily data, GPS data, key data and machine list of a machine can be exported.

First select the machine group and the machine. Also, limit the time period. Please don't choose a too long period of time, as more than 10,000 data sets will not be exported.

To open the settings, click on the black arrow on the right. The export settings will open. In the settings choose between Excel and CSV. For CSV, you can also determine which line separator should be used between the data records (line), which field separator should be used in each line between the values, and whether and in what type of quotation marks the individual values should be enclosed. Click "Save Settings" to permanently set your selection as the default.

If you want to process the data automatically, CSV is preferable. It contains the data in a simple, tabular format. Excel, on the other hand, focuses on clarity.

Click on one of the five buttons below to start exporting the desired data. Your browser should offer the choice of either saving the data to disk or opening it in a program.

Key functions (only available as an option, not included automatically)

If the EQTrace OPT+ is connected to the additionally purchased key module and the reading of keys on the Obserwando server is enabled, the activation of the output (and the machine) can be controlled via an electronic key.

The user logged in with the key is registered. The registration expires if the vehicle has been switched off for at least 30 seconds. Users who want to log in while the vehicle is running will not be registered.

Connection of the key module

The 5-pin connector of the key module is plugged into the socket on the EQTrace OPT+ module. If the function is enabled on the Obserwando server, keys are automatically recognized if they are authorized to operate the vehicle.



Use of the key function

To be able to use this function, please proceed as follows:

Create the users who are allowed to use keys.

Attention: The user does not have to be an Obserwando user!

Add key user

First name

Last name

Mobile phone

IPAF PAL-Card

Assign a key to each user. All free keys obtained from Rösler can be found under the corresponding menu.

User keys

Alarm, Auto

Keys handed out to Alarm, Auto

Key number	Machines	Aktion
3c007e002f2c8601	-	<input type="button" value="Retract"/>
freigegeben — zur Freigabe vorgemerkt — zur Sperrung vorgemerkt		
Add new user Add new key Delete key		

Under "Key access" you can individually determine which machines are released for each user. To do this, click on "Assign" for the relevant machines. The key is then reserved for release. Once you have completed the selection of the machines, the reserved keys must be transferred to the devices. To do this, click on "Connect". If a device is not available at this time, the process is set to repeat automatically. As soon as the device is connected to the server again, the data will be transmitted again.

Key access

User: Key, 00156 Group: all

Machine	Status	Startdatum/Startzeit	Stoppdatum/Stopzeit	Lock
11223344	Assigned	-	-	<input type="checkbox"/>
11223345	Assigned	-	-	<input type="checkbox"/>
20005245	Marked for assignment	-	-	<input type="checkbox"/>
20006298	Assigned	9 Jul 2019 09:49	10 Jul 2019 09:49	<input type="checkbox"/>
24242424	Assigned	-	-	<input type="checkbox"/>
30000046	Marked for assignment	-	-	<input type="checkbox"/>
WLAN39	Assigned	-	-	<input type="checkbox"/>

Machine	Status	Startdatum/Startzeit	Stoppdatum/Stopzeit	Assign
11223340	Locked	-	-	<input type="checkbox"/>
11223341	Locked	-	-	<input type="checkbox"/>
11223342	Locked	-	-	<input type="checkbox"/>
11223346	Locked	-	-	<input type="checkbox"/>
11223347	Locked	-	-	<input type="checkbox"/>
11223348	Locked	-	-	<input type="checkbox"/>
MRT250 (3238)	Locked	-	-	<input type="checkbox"/>
21116347	Locked	-	-	<input type="checkbox"/>
30002809	Locked	-	-	<input type="checkbox"/>
30004761	Locked	-	-	<input type="checkbox"/>
30006181	Locked	-	-	<input type="checkbox"/>
31111111	Locked	-	-	<input type="checkbox"/>
33001377	Locked	-	-	<input type="checkbox"/>
825836080	Locked	-	-	<input type="checkbox"/>
Stapler 1	Locked	-	-	<input type="checkbox"/>
MB4-L	Locked	-	-	<input type="checkbox"/>
Torsteuerung	Locked	-	-	<input type="checkbox"/>
G75484+	Locked	-	-	<input type="checkbox"/>

Evaluation of the key data

The evaluation of usage times can be carried out according to various aspects:

When using the key by machine, it is listed which users worked with the machine when and how long.

Key usage by machine

Machine group: all | Machine: 11223341 | from: 2023-01-01 | to: 2023-09-05 | Show

Connect

11223341 Different function Successful 15/08/2023 15:19

User name	Key number	Date	Start	Stop	Sum	
test, pinpad	0000000000002222	26 Jul 2023	12:21	13:17	00:57	▼
test, pinpad	0000000000002222	15 Aug 2023	14:36	17:22	02:47	▼
test, pinpad	0000000000002222	16 Aug 2023	12:46	14:52	02:07	▼
test, pinpad	0000000000002222	18 Aug 2023	11:10	11:48	00:39	▼

When using key usage by user, you can see all the machines that the user had worked during the period.

Key usage by user

User: Key, 00157 | from: 2023-01-01 | to: 2023-09-05 | Show

Connect

11110022	Send keys	Failed.	15/06/2023 14:03
11223340	Machine status	Successful	26/05/2021 15:22
11223342	Send keys	Failed.	15/06/2023 14:03
11223344	Different function	Successful	29/06/2023 11:57
11223345	Send new settings	Successful	29/06/2023 12:01
11223346	Send keys	Failed.	15/06/2023 14:03
11223348	Send keys	Failed.	15/06/2023 14:03
MRT2550 (3238)	Send keys	Failed.	15/06/2023 14:03
21116347	Send keys	Failed.	15/06/2023 14:03
24242424	Send keys	Failed.	15/06/2023 14:03
30007304	Machine status	Failed.	19/04/2023 12:05
31000467	Send keys	Failed.	15/06/2023 14:03
31111111	Send keys	Failed.	15/06/2023 14:03
33001377	Send keys	Failed.	15/06/2023 14:03
33331236	Send keys	Failed.	15/06/2023 14:03
WLAN39	Send keys	Failed.	15/06/2023 14:03
46464646	Send keys	Failed.	15/06/2023 14:03

Machine	Date	Start	Stop	Sum	
11223344	15 Jun 2023	14:03	16:13	02:11	▼
11223344	16 Jun 2023	09:30	09:42	00:13	▼
825836080	16 Jun 2023	11:53	11:55	00:03	▼
11223344	16 Jun 2023	16:28	17:19	00:52	▼

Technical data

	Base	Optional
Operating voltage:	10 – 60 <u>VDC</u>	
Input voltage:	10 – 60 <u>VDC</u>	
Input channels:	1 analogue	Up to 4 more digital
Outputs:		1
Vibration sensor:	1	
Shock sensor:		1
Rfid:		1
Operating temperatur:	-35°C - +65°C	
Power consumption:	At 12V: max. 120mA, 8,9mA in battery saving mode	
Transmission method:	<u>LTE</u> with national roaming (D1/D2/O2)	

Scope of delivery

1. EQTrace OPT+ including connection cable 2m