


EQTrace V+

LTE-GPS-Tracker



Position / Route



Theft protection

ATS settings

Machine group: all Machine: 11223340 [Choose](#)

General

☐ activate monitoring

Settings

☒ Automatically update centre of rest and work area at the end of a route

Rest area monitoring

Mon	to	06:00	e'clock	and again from	18:00	e'clock
Tue	to	06:00	e'clock	and again from	18:00	e'clock
Wed	to	06:00	e'clock	and again from	18:00	e'clock
Thu	to	06:00	e'clock	and again from	18:00	e'clock
Fri	to	06:00	e'clock	and again from	18:00	e'clock
Sat	up	00:00	e'clock	to	24:00	e'clock
Sun	up	00:00	e'clock	to	24:00	e'clock

work area

radius km

Usage time

cw	day of the week	Start	stop	total	actual - Eingang 1	
2017 - 13	30/03/2017 - Thursday	13:08	20:42	07:34	01:22	▼ 16
2017 - 14	04/04/2017 - Tuesday	09:18	17:13	07:55	04:47	▼ 16
2017 - 14	05/04/2017 - Wednesday	00:01	10:30	10:29	06:26	▼ 16
		Total		25:58	12:35	

Ready for use in just a few minutes:

- Connect EQTrace V+ to the vehicle via the OBD2 connector
- Collecting data during vehicle activity
- View / evaluate data on Obserwando.de or via app
- Can be used for all vehicles with OBD2 connection
- Quick and easy installation

Technical Data:

Operating voltage:	12V DC - 24V DC
Inputs:	2 virtuel (operating voltage and shock sensor)
Protection:	IP66
Operating temperatur:	-35°C – +65°C
Transfer procedure:	LTE

complete instructions:

